

KAYAKPRO[®]

DM, O1M and Canoe Ergometer Tablet holder installation

Disclaimer

Disclaimer. By using our KayakPro tablet holder - User accepts full responsibility for damage to self and product and any electronic devices. Caution and care must be exercised. Fast moving shafts and ropes will cause damage if impact ensues and care is not taken.



- 1 Place your Tablet holder on the flywheel of your Ergometer, behind the Numbered resistance decals to ensure continued use of the resistance lever.




- 2 Press down firmly until the tablet holder is located as far down as it can be onto the flywheel.

Holding the Tablet holder in place, using the pre-formed holes in the side of the tablet holder drill a 5mm hole in the flywheel casing, to one side only. Be careful to only penetrate the flywheel casing enough to ensure a clean 5mm hole through.



- 3 Once you have a hole made – Insert one of the push-in plastic studs to locate.



- 4 Once the stud is in place on one side – Drill the other side using the predrilled holes in the side of the base of the tablet holder. – Insert the second push-in plug.



- 5 Slide in your tablet to the holder. Adjust the vertical sliding support to fit and accommodate the width of your tablet, using the screws to secure. Same with the top sliding adjustable clip, to hold the top of your tablet.



All Done! You are all set. Let's paddle!

